

### How to Clean, Store and Maintain your Acrylic Light Pole Banners

Woven acrylic fabrics should be cleaned regularly before substances such as dirt, roof particles, etc. are allowed to accumulate on and become embedded in the fabric. The fabric can be cleaned without being removed from the installation. Simply brush off any loose dirt, roof particles, etc.; hose down and clean with mild solution of mild soap in lukewarm water (no more than 100° F). Rinse thoroughly to remove soap. DO NOT USE DETERGENTS. Allow to air dry.

For more stubborn cases: Soak the fabric for approximately twenty minutes in a solution of no more than 1/2 cup (4 oz.) of a non-chlorine bleach and 1/4 cup (2 oz.) milk soap per gallon of water at approximately 100° F. Rinse thoroughly in cold water to remove all of the soap. NOTE: Excessive soaking in non-chlorine bleach can deteriorate sewing threads. This method of cleaning may removed part of the water repellency and the fabric should receive an application of an air-curing fluorocarbon water repellent treatment, such as 303 Hi Tech Fabric Guard, if water repellency is a factor.

Before woven acrylic fabrics are stored, they should be cleaned and allowed to air dry. It is extremely important that the fabrics be absolutely, completely dry before storing! Individually roll banners and do not store in plastic or other non- breathable wraps. Cardboard or other breathable packaging is fine. Please store in a dry, well ventilated area.



**1.800.655.7311**

From outside of U.S. (1) 802-488-8789

472 Meadowland Drive Unit #5  
South Burlington VT 05403  
sales@projectgraphics.com  
www.projectgraphics.com